


### Troubleshooting:

Symptoms	Causes	Solutions
Can not switch the speaker on	Battery empty	Charge the battery
Unable to pair the speaker	Speaker is already switched on, and it is not in pairing mode	Refer to the section of "Pairing 2686 to mobile phone or other device"
during working no sound suddenly	Battery out of charge	Charge the battery
Buttons can not work suddenly	Product need to be reset	Press the RESET button

### Technical Specifications

Bluetooth support:	3.0+EDR
Maximum RF Range:	10 meters
Transmitting frequency:	2.4G HZ
Power supply:	DC 5 V/100-120mA
Battery:	3.7V 400mA lithium
Charging time:	Approx. 3 hours
Operating time:	Approx.6 hours
IP grade:	above IPX6
Unit weight:	Approx. 123g

### WATERPROOF BLUETOOTH SHOWER SPEAKER/ OUTDOOR PORTABLE BLUETOOTH SPEAKER USER MANUAL




Thank you for choosing our Waterproof Bluetooth shower speaker. Sincerely hope you will enjoy your music and phone call freely.

### Safety Instructions

Read this manual carefully before you use our waterproof Bluetooth speaker and keep this manual for future reference.

- Keep the device away from heat, direct sunlight and sharp edges.
- Keep the device away from naked flames.
- Do not insert any metal objects into the device in case of short circuit!
- To avoid a static charge, please do not use the device in an extremely dry climate.
- Do not repair the unit by yourself but contact an authorized specialist to help you.

## Product overview



## Accessories Included

1pc USB charging cable

1pc Carabiner

## Charging Integrated Battery

This Bluetooth speaker is powered support by integrated rechargeable Lithium Battery. Charge the battery as follows:

- 1.Insert the charging cable into the DC 5V socket on the unit. Connect the USB plug into a PC or AC/DC adapter. The LED indicator turns red and the battery is being charged.
- 2.When the battery is fully charged, the red LED indicator goes out.

## Pairing 2686 to Mobile phone or other device

Active the Bluetooth speaker pairing mode by button and then there has a voice reminder says: Enter to Bluetooth. the blue LED is flashing ,means the speaker is ready for pairing. Switch off the mobile phone Bluetooth, the speaker will says: Bluetooth canceled.

## Tips:

Please make sure the speaker is in power off mode when you are trying to activate the pairing mode.

- 1.Turn on your mobile Phone and activate the Bluetooth function.
- 2.Search for Bluetooth devices, 2686 will show up.
- 3.Pair your device with 2686. If password is needed, type in "0000" ,after 2686 is paired with your device, voice reminder says: Bluetooth connected, means the speaker had connected with your device.

## Tips:

Once this speaker is paired and connected to your mobile phone, next time when you switch on this speaker, it will connect to your mobile phone automatically as long as the Bluetooth in your mobile phone is on.

## Button description



On/Off : To switch on or off the device



Short press for the previous song, long press for turning down the volume.



Short press for the next song, long press for turning up the volume.



Phone: To pick up or hang up a phone call.




Play/pause the music

- RESET button: Press the button heavily to reset the speaker

## Notes & tips:

- 1.You can press Phone Button twice quickly to redial the last phone No. Call.

Long press the Phone answering Button  3 seconds, disconnected from the connection between phone and Bluetooth speaker